


ASSEMBLY INSTRUCTION

TV 62


TV Cabinet



ASSEMBLY INSTRUCTION

TV 62











TV Cabinet





ASSEMBLY INSTRUCTION

TV 62 TV Cabinet

PART LIST



1  Top Panel 1 PC	2  Side Panel L 1 PC	3  Side Panel R 1 PC	4  Center Panel L 1 PC
5  Center Panel R 1 PC	6  Bottom Panel 1 PC	7  Back Panel 1 PC	8  Middle Panel 1 PC
9  Shelf Panel 1 PC	10  Door Panel 1 PC		

HARDWARE LIST

A  Camlock 15MM 12 PCS	B  Camlock Bolt 15MM 12 PCS	C  M8x25MM Wood Dowel 20 PCS	D  CB Screw M3.5x16MM 32 PCS
E  Sticker 12 PCS	F  Nail 5/8 30 PCS	G  Csk M6x50MM 8 PCS	H  PVC Square Leg 5 PCS
I  M4 Allen Key 1 PC	J  Soft Close Hinges 7/8 2 PCS	K  Shelf Support 4 PCS	







ASSEMBLY INSTRUCTION

Step 1



Required/Requis/Requerido





x16



Step 2

Required/Requis/Requerido

x12




ASSEMBLY INSTRUCTION

Step 3

Required/Requis/Requerido


x20	 D
x5	 H



Step 4

Required/Requis/Requerido


x4	 K
----	---



ASSEMBLY INSTRUCTION


Step 5

Required/Requis/Requerido		
x4		A
x4		E



Step 6




Required/Requis/Requerido		
x8		G
x1		I



ASSEMBLY INSTRUCTION


Step 7

Required/Requis/Requerido		
x8		A
x8		E




Step 8

Required/Requis/Requerido		
x30		F




Rear View



ASSEMBLY INSTRUCTION

Step 9




Step 10

Required/Requis/Requerido

x4  D

x2  J







ASSEMBLY INSTRUCTION

Step 11

Required/Requis/Requerido

x8



Completed

