


ASSEMBLY INSTRUCTION

TV 60


TV Cabinet



ASSEMBLY INSTRUCTION

TV 60










TV Cabinet




ASSEMBLY INSTRUCTION

TV 60 TV Cabinet

PART LIST


1  Top Panel 1 PC	2  Side Panel L 1 PC	3  Side Panel R 1 PC	4  Center Panel L 1 PC
5  Center Panel R 1 PC	6  Bottom Panel 1 PC	7  Back Panel 1 PC	8  Middle Panel 1 PC
9  Door Panel L/R 2 PCS			

HARDWARE LIST

A  Camlock 15MM 12 PCS	B  Camlock Bolt 15MM 12 PCS	C  M8x25MM Wood Dowel 20 PCS	D  CB Screw M3.5x16MM 40 PCS
E  Sticker 12 PCS	F  Nail 5/8 20 PCS	G  Csk M6x50MM 8 PCS	H  PVC Square Leg 4 PCS
I  M4 Allen Key 1 PC	J  Soft Close Hinges 7/8 4 PCS		








ASSEMBLY INSTRUCTION

Step 1



Required/Requis/Requerido





x20



Step 2

Required/Requis/Requerido

x12





ASSEMBLY INSTRUCTION

Step 3

Required/Requis/Requerido



x16	 D
x4	 H



Step 4


Required/Requis/Requerido


x4	 A
x4	 E



ASSEMBLY INSTRUCTION




Step 5

Required/Requis/Requerido	
x8	 G
x1	 I



Step 6

Required/Requis/Requerido	
x8	 A
x8	 E





ASSEMBLY INSTRUCTION

Step 7


Required/Requis/Requerido

x20



Rear View

Fx20





Step 8

Required/Requis/Requerido

x8



x4







ASSEMBLY INSTRUCTION

Step 9

Required/Requis/Requerido

x16



Completed

