


ASSEMBLY INSTRUCTION

TV 63


TV Cabinet



ASSEMBLY INSTRUCTION

TV 63

TV Cabinet












ASSEMBLY INSTRUCTION



TV 63

TV Cabinet

PART LIST



1  Top Panel 1 PC	2  Side Panel L 1 PC	3  Side Panel R 1 PC	4  Center Panel L 1 PC
5  Center Panel R 1 PC	6  Bottom Panel 1 PC	7  Back Panel 1 PC	8  Middle Panel 1 PC
9  Door Panel L/R 2 PCS			

HARDWARE LIST

A  Camlock 15MM 12 PCS	B  Camlock Bolt 15MM 12 PCS	C  M8x25MM Wood Dowel 20 PCS	D  CB Screw M3.5x16MM 44 PCS
E  Sticker 12 PCS	F  Nail 5/8 30 PCS	G  Csk M6x50MM 8 PCS	H  PVC Square Leg 5 PCS
I  M4 Allen Key 1 PC	J  Soft Close Hinges 7/8 4 PCS		

ASSEMBLY INSTRUCTION



Step 1




Required/Requis/Requerido

x20


C




R View



R View



L View





L View

Step 2


Required/Requis/Requerido

x12


B



R View



L View




Bottom View

ASSEMBLY INSTRUCTION

Step 3

Required/Requis/Requerido


x20	 D
x5	 H



Step 4


Required/Requis/Requerido


x4	 A
x4	 E



ASSEMBLY INSTRUCTION


Step 5

Required/Requis/Requerido	
x8	 G
x1	 I



Step 6

Required/Requis/Requerido	
x8	 A
x8	 E




ASSEMBLY INSTRUCTION


Step 7

Required/Requis/Requerido


x30



F



Rear View



Fx30

Step 8

Required/Requis/Requerido

x8




D

x4



J




ASSEMBLY INSTRUCTION

Step 9

Required/Requis/Requerido

x16



Completed

