


ASSEMBLY INSTRUCTION

TV 58


TV Cabinet



ASSEMBLY INSTRUCTION

TV 58








TV Cabinet




ASSEMBLY INSTRUCTION

TV 58 TV Cabinet

PART LIST


1  Top Panel 1 PC	2  Side Panel L 1 PC	3  Side Panel R 1 PC	4  Center Panel 1 PC
5  Middle Panel 1 PC	6  Bottom Panel 1 PC	7  Back Panel 1 PC	

HARDWARE LIST

A  Camlock 15MM 10 PCS	B  Camlock Bolt 15MM 10 PCS	C  M8x25MM Wood Dowel 16 PCS	D  CB Screw M3.5x16MM 16 PCS
E  Sticker 10 PCS	F  Nail 5/8 20 PCS	G  Csk M6x50MM 6 PCS	H  PVC Square Leg 4 PCS
I  M4 Allen Key 1 PC			







ASSEMBLY INSTRUCTION

Step 1



Required/Requis/Requerido





x16



Step 2

Required/Requis/Requerido

x10





ASSEMBLY INSTRUCTION

Step 3

Required/Requis/Requerido




x16	 D
x4	 H



Step 4


Required/Requis/Requerido


x4	 A
x4	 E



ASSEMBLY INSTRUCTION




Step 5

Required/Requis/Requerido	
x6	 G
x1	 I



Step 6


Required/Requis/Requerido	
x6	 A
x6	 E



ASSEMBLY INSTRUCTION

Step 7

Required/Requis/Requerido		
x20		F



Completed

